

**Item #: 894500**  
**BRAND & PRODUCT TYPE**

## **JUSTRITE® FM Approved Cabinets**

### **DESCRIPTION**

Yellow FM approved cabinet 1092mm L x 457mm W x 1651mm H, 2 manual close doors and 2 shelves.

### **EXTENDED DESCRIPTION**

STEEL Flammable Liquids Under-Bench Cabinet FM Type - 894500 Manufactured from 1mm steel with 38mm insulating air gap between the walls this fully welded cabinet has manually operated twin doors hung on continuous piano hinges which are fitted with a 3-point lockable latch to hold it closed under fire conditions. High and low level vents fitted with flame arrestor allow air flow and the cabinet has a durable powder-coat paint finish inside and out. The cabinet is FM (Factory Mutual) tested and approved and comes with a 10-year manufacturer warranty.

